



Concrete Base Formwork Set-Up Guide

Using Concrete4U & Lightwater Quarries Aggregates



CONCRETE 4U



HVO
FUELING A
GREENER FUTURE




Setting Up Formwork For A Concrete Base

Setting up formwork is a critical step in preparing for a concrete pour. Properly constructed formwork ensures that the concrete base will have the correct dimensions, shape, and strength.

Read the step-by-step guide to help you set up formwork for a concrete base.

Keep reading to learn more

CONCRETE 4U



Materials & Tools

- **Form Boards:** Typically 2x4s, 2x6s or heavy-duty plywood sheets
- **Stakes:** Wooden or metal stakes (long enough to ensure 2/3 are in the ground and 1/3 exposed)
- **Nails or Screws:** To secure the form boards
- **String Line:** For making and levelling. Rebar chairs or spacers (optional), for reinforcement support.
- **Tape Measure**
- **Hammer or Drill with screwdriver**
- **Saw:** Circular or Handsaw
- **Spirit Level**
- **Square**
- **Shovel & Mallet**
- **Laser Level:** for large areas

Step by Step Guide

1. Plan & Measure

■ **Determine the Size and Shape:**

Determine the exact dimensions and shape of the concrete base. Whether it's a square, rectangle or more complex shape, knowing the precise measurements is essential.

■ **Mark The Corners:** Use wooden or metal stakes to mark the corners of the base area. This will serve as a guide for placing your form boards.

2. Prepare the Ground

- **Clear the Area:** Remove any debris, grass or vegetation where the concrete will be poured. The ground should be as flat and level as possible.
- **Excavate if Necessary:** If the base requires it, excavate to the desired depth. The depth of the excavation will depend on the thickness of the concrete slab and the sub-base material.

2. Setting Up Formwork


- **Cut the Form Boards to Length:** Measure and cut your form boards to the desired length based on your layout. If you're using 2x4s or 2x6s, ensure they are long enough to span the entire length or width of the concrete base if possible.
- **For Corners:** You can mitre the ends at a 45-degree angle for a precise fit, but square cuts will be sufficient.

Assemble the Formwork

- **Layout the Boards:** Position the form boards along the perimeter of the area marked by your stakes. Make sure the boards are aligned with your measurements.
- **Join the Corners:** At each corner, secure the form boards together using nails or screws. Use a 'square' to ensure the corners are at a 90-degree angle unless you're working with angled or irregular shape.
- **Double-Check Dimensions:** After assembling the boards, measure the diagonals of the form to ensure that the base is square. The diagonals should be equal for a square or rectangular base.

Staking the Formwork:

- **Stakes:** Place stakes at regular intervals along the outside of the form boards. Generally, stakes should be placed every 2-4 feet, but closer spacing may be needed for larger or more complex forms.



Brace the Formwork (if needed):

- **Add Bracing:** If your formwork is tall (e.g. for thick slabs) or if the concrete pour will be large and heavy, add diagonal braces to the stakes. This prevents the form boards from bowing outward under the pressure of the concrete.
- **Secure the Braces:** Nail or screw the braces to both the stakes and the form boards. This is especially important for the longer sides of the formwork.

4. Additional Features

- **Reinforcement Supports:** If your concrete base requires reinforcement (such as rebar or mesh), consider placing rebar chairs or spacers within the formwork at this stage. This ensures that the reinforcement will be correctly positioned in the concrete, but make sure these do not interfere with the placement of the concrete later.

- • **Expansion Joints:** If the concrete base is
 - large, you may need to install expansion
 - joints within the formwork. These joints allow
 - for thermal expansion and contraction
 - without cracking the concrete. Place the
 - joint strips or boards at regular intervals
 - across the formwork.

5. Final Checks

- **Inspect the Formwork:** Walk around the entire perimeter and check for any gaps, mis-alignments, or weak spots. Make sure all joints are secure and the formwork is sturdy. Verify that the top edges of the form boards are level all the way around.
- **Correct Dimensions:** Re-measure the formwork to confirm it matches the intended dimensions of your concrete base. Check the height, width, and length.

6. Secure the Formwork (Optional)

- **Apply a Release Agent:** If you plan to reuse the form boards or want to make removal easier, consider applying a release agent (like a light oil or commercial form release product) to the inside surfaces of the formwork.
- **Re-Check Stake Stability:** Ensure all stakes are firmly in the ground and that the form boards are tightly secured to them. This will prevent any movement when the concrete is poured.

7. Tips & Considerations

- **Use High-Quality Lumber:** Choose straight, sturdy lumber for the form boards to avoid warping and to ensure the concrete base has smooth, straight edges.

- **Work With A Partner:** Setting up formwork is easier and more accurate with two people, especially when handling long boards and ensuring everything is level.
- **Adapt The Site Conditions:** If the ground is uneven, you may need to dig out high spots or fill in low areas under the form boards to ensure a level formwork setup.
- **Double-Check Everything:** Before moving on to the concrete pour, make sure all measurements, levels and alignments are correct. Mistakes in the formwork will directly affect the quality of the finished concrete base.
- **Check The Depth:** Use the tamping board to check the depth by placing across the formwork in several places and measure from the bottom of the board to the top of the aggregate (this will ensure the accuracy of concrete volume required).

By following this guide, you'll create a sturdy and accurate formwork structure, providing a solid foundation for your concrete base. Properly setting up the formwork is crucial for ensuring the concrete pour goes smoothly and the finished slab meets your project's specifications.



Why Choose Concrete4U & Lightwater Quarries?


Concrete4U provides a wide range of ready-mix and volumetric concrete solutions tailored to your specific needs, ensuring the best quality for your project.

Lightwater Quarries offers quality aggregates that are essential for creating a strong and stable base, available in various sizes and types.

Start your project with confidence. Visit **Concrete4U** and **Lightwater Quarries** today to get the best materials for your concrete base!



CONCRETE 4U



HVO
FUELING A
GREENER FUTURE